IDS805 Programming

IDS805 panels with **grey serial cable** on external serial connector

---

Basic Programming

Locations 43 to 46

- Enter **[Account code]**

Location 47

- Enter **6** (Contact ID)

Locations 48 to 54

- Enter **5555555**

Location 151

- Default is 4 dial attempts
- Enter **0** to disable the dialer

Important Notes

- Tone and force dialling are enabled by default
- **LTE GSM must be powered directly from battery**
- Do not power from panel auxiliary output

App Configuration

For mobile app connectivity:

Requirements:

- App version **v4.37** or latest **vE4.xx**
- Serial Port must be set to **Orisec/IDS805**
- Requires a **VALID user code**

Troubleshooting

- If no communication, verify power is from battery

- Test with known working user code

Revision #1
Created 30 July 2026 09:30:03 by Jonathan Cox
Updated 30 July 2026 09:30:03 by Jonathan Cox