IDS806 Programming

IDS806 panels with **red serial cable**

Basic Programming

Locations 43 to 46

- Enter **[Account code]**

Location 47

- Enter **6** (Contact ID)

Locations 48 to 54

- Enter **5555555**

Location 196

- Must be **000000**
- Critical for proper operation

Installation Procedure

Important: Follow this exact sequence:

1. Ensure panel power is **OFF**
2. Connect serial port only (no panel power)
3. Power up the panel
4. Serial port will be automatically detected

Tested Versions

Successfully tested on firmware versions:

- 1.12
- 1.13
- 1.14
- 1.15
- 1.88

Critical Notes

- Location 196 must be all zeros
- Panel reboot required after serial connection
- Red serial cable indicates IDS806 compatibility

Revision #1
Created 30 July 2026 09:30:03 by Jonathan Cox
Updated 7 August 2026 13:28:56 by Jonathan Cox