Orisec Configuration

Orisec panels support both Tip/Ring and Com Port connections

Orisec Tip/Ring Configuration

1. Enter **Installer Code**
2. Select **Programming Menu** → Tick/Enter
3. Go to **ARC Set up**
4. **Phone Number**: 555 5555
5. **Account Number**: As supplied by control room/software
6. **Protocol**: Contact ID
7. **Dial Seq**: 1
8. Any issues with not sending - **RESTART PANEL**

Orisec Com Port Configuration

1. Enter **Installer Code**
2. Select **Programming Menu** → Tick/Enter
3. **Com Port Setup** → Tick/Enter
4. Select **Com Port number 2**
5. Set mode to **FINMON** (Required for app)
6. **Hold Tick** to go back
7. Go to **ARC Set up**
8. **Phone Number**: F555 5555 (Note the 'F' prefix)
9. **Account Number**: As supplied by control room/software
10. **Protocol**: Contact ID
11. **Dial Seq**: 6
12. Any issues with not sending - **RESTART PANEL**

App Configuration

Requirements:

- App version must be **v4.37**
- Serial Port must be set to **Orisec/IDS**
- **MUST** be set to FINMON under Comm Port Setup

Critical Notes

IF YOU AREN'T GETTING SIGNALS OUT:

- **REBOOT THE PANEL**
- If serial port connected with panel powered up, it won't be detected
- Always power cycle after connecting serial

Revision #2
Created 10 June 2025 12:52:02 by Calvin van Wieringen
Updated 19 June 2025 13:23:20 by Jonathan Cox