Texecom MiAlarm PANEL MODE

Configuration for MiAlarm compatibility

Note: Texecom Elite panels are NOT supported on app, but work with serial for CID

Programming Steps

1. **Enter Programming Mode**
   - Enter Installer Code
   - Press Menu button
   - Press 9
2. **Location 76/0**
   - Press location 76
   - Press sublocation 0
   - Ensure LED 1 is **ON**
   - If not ON: Press 1, then YES/Tick button
3. **Location 76/2**
   - Press location 76
   - Press sublocation 2
   - Enter UDL code: **1234**
   - Press YES/Tick button
4. **Location 76/5**
   - Press location 76
   - Press sublocation 5
   - Press **3**
5. **Exit Programming**
   - Press Menu button
   - Press 99

Important Notes

- This configuration enables MiAlarm compatibility

Revision #2
Created 10 June 2025 12:51:40 by Calvin van Wieringen
Updated 19 June 2025 13:21:58 by Jonathan Cox