

IDS806 Dialler Programming

Basic Dialler Programming

Locations 43 to 46

- Enter **[Account code]**

Location 47

- Enter **6** (Contact ID)

Locations 48 to 54

- Enter **5555555**

Revision #3

Created 10 June 2025 12:32:42 by Calvin van Wieringen

Updated 7 August 2026 13:28:39 by Jonathan Cox