

# Caddx Standard Programming

Standard Caddx panels connected via Tip & Ring

---

## Location Programming

### Location 0

- Segment 1 = **13** (force dial)
- Segment 2 = **15** (Tone dialling)
- Segment 3 to 9 = **5555555** (Tel number)

### Location 1

- Segment 1 to 4 = **[account code]**

### Location 2

- Enter **1** for Contact ID
  - On older panels: Enter **13**
- 

## Partition Account Codes

If using multiple partitions, program account codes for each:

- **Location 89** - Partition 2 account code
  - **Location 92** - Partition 3 account code
  - **Location 95** - Partition 4 account code
- 

## Important Notes

- Force dial (segment 1 = 13) is critical for Caddx panels
  - Always verify tone dialling is enabled (segment 2 = 15)
  - Test each partition if multiple partitions are programmed
  - Older panels may require "13" in Location 2 instead of "1"
- 

Revision #1

Created 10 June 2025 10:20:32 by Calvin van Wieringen

Updated 10 June 2025 10:20:48 by Calvin van Wieringen