

Paradox Evo 848 Programming

Older Evo model programming

Basic Programming

Location 521 (Dialer options)

- LED 3, 4, 5, 6 must be **ON**
- All others **OFF**

Location 550 (Format Contact ID)

- Enter **5555**

Location 551

- Enter **[4-digit account code]**

Location 561

- Enter **[Phone number]**
-

Important Notes

After Programming:

- Always **REBOOT** the panel after completing programming

Account Code Rules:

- **NEVER** use account codes starting with "0" (e.g., 0001)
 - Use 1001 instead
 - Can use hex A: 1AA1 (press "stay" button for hex A)
-

Troubleshooting

1. Panel not communicating after programming
 - Reboot is mandatory
 - Check all LEDs in location 521
2. Account code issues
 - Avoid leading zeros
 - Try hex characters if numeric codes fail

Revision #2

Created 10 June 2025 12:48:38 by Calvin van Wieringen

Updated 19 June 2025 13:14:13 by Jonathan Cox