Risco Configuration

Complete programming guide for Risco panels

Accessing Programming

1. Press **MENU BUTTON**
2. Enter **INSTALLER CODE** (Default: 1111)
3. Navigate to **"PROGRAMMING"** → ENTER
4. Navigate to **"COMMUNICATION"** → ENTER

Monitoring Station Setup

Navigate to **"MONITORING STATION (MS)"** → ENTER
Navigate to **"MONITORING STATION 1 (MS 1)"** → ENTER

Configure the following:

- **TYPE** = VOICE
- **CHANNEL** = PSTN/GSM
- **ACCOUNT** = 6 digit code provided by office (e.g., 001052)
- **PHONE** = 555 555 5
- **MS RETRIES** = 3

Timer Configuration

Navigate to **"TIMERS"**:

- **CANCEL DELAY** = 0
- **ABORT ALARM** = 0

Periodic Test Setup

Navigate to **"PERIODIC TEST"**:

- **TIME** = 2200 (for 10:00 PM test)
- **RECURRENCE** = EVERY 1 DAY

Report Split Configuration

Navigate to **"REPORT SPLIT"**:

- **ARM/DISARM** = "NON" for DOMESTIC / "CALL MS1 ONLY" for COMMERCIAL
- **MS URGENT** = "CALL MS1 ONLY"
- **MS NON URGENT** = "CALL MS1 ONLY"

Cloud Settings

Back to main COMMUNICATION menu
Navigate to **"CLOUD"**:

- **MS CALL ALL** = ENABLED
- **FM CALL ALL** = ENABLED

Exit Programming

1. Press MENU
2. Press MENU
3. Press MENU, 0, ENTER to exit

Revision #2
Created 10 June 2025 12:52:25 by Calvin van Wieringen
Updated 19 June 2025 13:24:47 by Jonathan Cox