Zone Management

Zone Management

Zone Status Indicators

Color	Status	Meaning
◫ Green	Clear	Zone secure, no activity
◫ Blue	Bypassed	Zone disabled temporarily
◫ Red	Violated	Zone triggered/open
◫ Orange	Restored	Was violated, now clear

Managing Zones

View All Zones:

1. Tap grid icon
2. Heatmap shows all zones
3. Filter by status/area
4. Click for details

Edit Zone Info:

1. Tap the Zones Grid Icon
2. Select relevant Zone number
3. Tap Edit Zone
4. Update:
   - Zone name
   - Triggered Text
   - Clear Text
5. Save changes

? Bypassing Zones {#bypass}

What is Bypassing?

Temporarily disable specific zones while keeping others active.

When to Bypass

- Faulty sensor
- Maintenance work
- Leaving window open
- Pet in secured area
- Temporary access needed

How to Bypass

Method 1: Zone List

1. Expand area card
2. Find zone to bypass
3. Toggle switch OFF
4. Zone turns blue

Method 2: Heatmap

1. Switch to heatmap view
2. Tap zone tile
3. Select "Bypass"
4. Confirm action

Method 3: Quick Swipe

1. In zone list
2. Swipe right on zone
3. Quick bypass toggle

Managing Bypassed Zones

View All Bypassed:

1. Heatmap view
2. Filter → "Bypassed"
3. Shows blue zones only

Clear All Bypasses:

1. Disarm area
2. Re-arm without bypass
3. Or manually unbypass each

Bypass Notifications:

- Alert when zones bypassed
- Status in notifications

Revision #5
Created 10 June 2025 09:48:28 by Calvin van Wieringen

Updated 5 January 2026 13:03:18 by Kade Bhugwathideen