

Chapter 7: Other Panels

- [Orisec Configuration](#)
- [Risco Configuration](#)

Orisec Configuration

Orisec panels support both Tip/Ring and Com Port connections

Orisec Tip/Ring Configuration

1. Enter **Installer Code**
 2. Select **Programming Menu** → Tick/Enter
 3. Go to **ARC Set up**
 4. **Phone Number:** 555 5555
 5. **Account Number:** As supplied by control room/software
 6. **Protocol:** Contact ID
 7. **Dial Seq:** 1
 8. Any issues with not sending - **RESTART PANEL**
-

Orisec Com Port Configuration

1. Enter **Installer Code**
 2. Select **Programming Menu** → Tick/Enter
 3. **Com Port Setup** → Tick/Enter
 4. Select **Com Port number 2**
 5. Set mode to **FINMON** (Required for app)
 6. **Hold Tick** to go back
 7. Go to **ARC Set up**
 8. **Phone Number:** F555 5555 (Note the 'F' prefix)
 9. **Account Number:** As supplied by control room/software
 10. **Protocol:** Contact ID
 11. **Dial Seq:** 6
 12. Any issues with not sending - **RESTART PANEL**
-

App Configuration

Requirements:

- App version must be **v4.37**
 - Serial Port must be set to **Orisec/IDS**
 - **MUST** be set to FINMON under Comm Port Setup
-

Critical Notes

IF YOU AREN'T GETTING SIGNALS OUT:

- **REBOOT THE PANEL**

- If serial port connected with panel powered up, it won't be detected
 - Always power cycle after connecting serial
-

Risco Configuration

Complete programming guide for Risco panels

Accessing Programming

1. Press **MENU BUTTON**
 2. Enter **INSTALLER CODE** (Default: 1111)
 3. Navigate to "**PROGRAMMING**" → ENTER
 4. Navigate to "**COMMUNICATION**" → ENTER
-

Monitoring Station Setup

Navigate to "**MONITORING STATION (MS)**" → ENTER

Navigate to "**MONITORING STATION 1 (MS 1)**" → ENTER

Configure the following:

- **TYPE** = VOICE
 - **CHANNEL** = PSTN/GSM
 - **ACCOUNT** = 6 digit code provided by office (e.g., 001052)
 - **PHONE** = 555 555 5
 - **MS RETRIES** = 3
-

Timer Configuration

Navigate to "**TIMERS**":

- **CANCEL DELAY** = 0
 - **ABORT ALARM** = 0
-

Periodic Test Setup

Navigate to "**PERIODIC TEST**":

- **TIME** = 2200 (for 10:00 PM test)
 - **RECURRENCE** = EVERY 1 DAY
-

Report Split Configuration

Navigate to "**REPORT SPLIT**":

- **ARM/DISARM** = "NON" for DOMESTIC / "CALL MS1 ONLY" for COMMERCIAL
 - **MS URGENT** = "CALL MS1 ONLY"
 - **MS NON URGENT** = "CALL MS1 ONLY"
-

Cloud Settings

Back to main COMMUNICATION menu

Navigate to "**CLOUD**":

- **MS CALL ALL** = ENABLED
 - **FM CALL ALL** = ENABLED
-

Exit Programming

1. Press MENU
 2. Press MENU
 3. Press MENU, 0, ENTER to exit
-