

Orisec Configuration

Orisec panels support both Tip/Ring and Com Port connections

Orisec Tip/Ring Configuration

1. Enter **Installer Code**
 2. Select **Programming Menu** → Tick/Enter
 3. Go to **ARC Set up**
 4. **Phone Number:** 555 5555
 5. **Account Number:** As supplied by control room/software
 6. **Protocol:** Contact ID
 7. **Dial Seq:** 1
 8. Any issues with not sending - **RESTART PANEL**
-

Orisec Com Port Configuration

1. Enter **Installer Code**
 2. Select **Programming Menu** → Tick/Enter
 3. **Com Port Setup** → Tick/Enter
 4. Select **Com Port number 2**
 5. Set mode to **FINMON** (Required for app)
 6. **Hold Tick** to go back
 7. Go to **ARC Set up**
 8. **Phone Number:** F555 5555 (Note the 'F' prefix)
 9. **Account Number:** As supplied by control room/software
 10. **Protocol:** Contact ID
 11. **Dial Seq:** 6
 12. Any issues with not sending - **RESTART PANEL**
-

App Configuration

Requirements:

- App version must be **v4.37**
 - Serial Port must be set to **Orisec/IDS**
 - **MUST** be set to FINMON under Comm Port Setup
-

Critical Notes

IF YOU AREN'T GETTING SIGNALS OUT:

- **REBOOT THE PANEL**

- If serial port connected with panel powered up, it won't be detected
 - Always power cycle after connecting serial
-

Revision #1

Created 30 July 2026 09:30:04 by Jonathan Cox

Updated 30 July 2026 09:30:04 by Jonathan Cox