

# Chapter 7: Other Panels

- [Orisec Configuration](#)
- [Risco Configuration](#)

# Orisec Configuration

Orisec panels support both Tip/Ring and Com Port connections

---

## Orisec Tip/Ring Configuration

1. Enter **Installer Code**
  2. Select **Programming Menu** → Tick/Enter
  3. Go to **ARC Set up**
  4. **Phone Number**: 555 5555
  5. **Account Number**: As supplied by control room/software
  6. **Protocol**: Contact ID
  7. **Dial Seq**: 1
  8. Any issues with not sending - **RESTART PANEL**
- 

## Orisec Com Port Configuration

1. Enter **Installer Code**
  2. Select **Programming Menu** → Tick/Enter
  3. **Com Port Setup** → Tick/Enter
  4. Select **Com Port number 2**
  5. Set mode to **FINMON** (Required for app)
  6. **Hold Tick** to go back
  7. Go to **ARC Set up**
  8. **Phone Number**: F555 5555 (Note the 'F' prefix)
  9. **Account Number**: As supplied by control room/software
  10. **Protocol**: Contact ID
  11. **Dial Seq**: 6
  12. Any issues with not sending - **RESTART PANEL**
- 

## App Configuration

### Requirements:

- App version must be **v4.37**
  - Serial Port must be set to **Orisec/IDS**
  - **MUST** be set to FINMON under Comm Port Setup
- 

## Critical Notes

**IF YOU AREN'T GETTING SIGNALS OUT:**

- **REBOOT THE PANEL**

- If serial port connected with panel powered up, it won't be detected
  - Always power cycle after connecting serial
-

# Risco Configuration

Complete programming guide for Risco panels

---

## Accessing Programming

1. Press **MENU BUTTON**
  2. Enter **INSTALLER CODE** (Default: 1111)
  3. Navigate to "**PROGRAMMING**" → ENTER
  4. Navigate to "**COMMUNICATION**" → ENTER
- 

## Monitoring Station Setup

Navigate to "**MONITORING STATION (MS)**" → ENTER

Navigate to "**MONITORING STATION 1 (MS 1)**" → ENTER

Configure the following:

- **TYPE** = VOICE
  - **CHANNEL** = PSTN/GSM
  - **ACCOUNT** = 6 digit code provided by office (e.g., 001052)
  - **PHONE** = 555 555 5
  - **MS RETRIES** = 3
- 

## Timer Configuration

Navigate to "**TIMERS**":

- **CANCEL DELAY** = 0
  - **ABORT ALARM** = 0
- 

## Periodic Test Setup

Navigate to "**PERIODIC TEST**":

- **TIME** = 2200 (for 10:00 PM test)
  - **RECURRENCE** = EVERY 1 DAY
- 

## Report Split Configuration

Navigate to "**REPORT SPLIT**":

- **ARM/DISARM** = "NON" for DOMESTIC / "CALL MS1 ONLY" for COMMERCIAL
  - **MS URGENT** = "CALL MS1 ONLY"
  - **MS NON URGENT** = "CALL MS1 ONLY"
- 

## Cloud Settings

Back to main COMMUNICATION menu

Navigate to "**CLOUD**":

- **MS CALL ALL** = ENABLED
  - **FM CALL ALL** = ENABLED
- 

## Exit Programming

1. Press MENU
  2. Press MENU
  3. Press MENU, 0, ENTER to exit
-