Chapter 7: Other Panels

- Orisec Configuration
- Risco Configuration

Orisec Configuration

Orisec panels support both Tip/Ring and Com Port connections

Orisec Tip/Ring Configuration

1. Enter **Installer Code**
2. Select **Programming Menu** → Tick/Enter
3. Go to **ARC Set up**
4. **Phone Number**: 555 5555
5. **Account Number**: As supplied by control room/software
6. **Protocol**: Contact ID
7. **Dial Seq**: 1
8. Any issues with not sending - **RESTART PANEL**

Orisec Com Port Configuration

1. Enter **Installer Code**
2. Select **Programming Menu** → Tick/Enter
3. **Com Port Setup** → Tick/Enter
4. Select **Com Port number 2**
5. Set mode to **FINMON** (Required for app)
6. **Hold Tick** to go back
7. Go to **ARC Set up**
8. **Phone Number**: F555 5555 (Note the 'F' prefix)
9. **Account Number**: As supplied by control room/software
10. **Protocol**: Contact ID
11. **Dial Seq**: 6
12. Any issues with not sending - **RESTART PANEL**

App Configuration

Requirements:

- App version must be **v4.37**
- Serial Port must be set to **Orisec/IDS**
- **MUST** be set to FINMON under Comm Port Setup

Critical Notes

IF YOU AREN'T GETTING SIGNALS OUT:

- **REBOOT THE PANEL**
- If serial port connected with panel powered up, it won't be detected
- Always power cycle after connecting serial

Risco Configuration

Complete programming guide for Risco panels

Accessing Programming

1. Press **MENU BUTTON**
2. Enter **INSTALLER CODE** (Default: 1111)
3. Navigate to **"PROGRAMMING"** → ENTER
4. Navigate to **"COMMUNICATION"** → ENTER

Monitoring Station Setup

Navigate to **"MONITORING STATION (MS)"** → ENTER
Navigate to **"MONITORING STATION 1 (MS 1)"** → ENTER

Configure the following:

- **TYPE** = VOICE
- **CHANNEL** = PSTN/GSM
- **ACCOUNT** = 6 digit code provided by office (e.g., 001052)
- **PHONE** = 555 555 5
- **MS RETRIES** = 3

Timer Configuration

Navigate to **"TIMERS"**:

- **CANCEL DELAY** = 0
- **ABORT ALARM** = 0

Periodic Test Setup

Navigate to **"PERIODIC TEST"**:

- **TIME** = 2200 (for 10:00 PM test)
- **RECURRENCE** = EVERY 1 DAY

Report Split Configuration

Navigate to **"REPORT SPLIT"**:

- **ARM/DISARM** = "NON" for DOMESTIC / "CALL MS1 ONLY" for COMMERCIAL
- **MS URGENT** = "CALL MS1 ONLY"
- **MS NON URGENT** = "CALL MS1 ONLY"

Cloud Settings

Back to main COMMUNICATION menu
Navigate to **"CLOUD"**:

- **MS CALL ALL** = ENABLED
- **FM CALL ALL** = ENABLED

Exit Programming

1. Press MENU
2. Press MENU
3. Press MENU, 0, ENTER to exit
